

Warnings

The installation of this thermostat must be performed by a certified electrician and comply with the national and local electrical codes and regulations.

Before starting the installation of your new thermostat, make sure that the breakers for your heating system are off at the main electrical panel!


OTH3600-GA-V2

Installation Guide


Non-Programmable Thermostat for Floor Heating System

INSTALL YOUR THERMOSTAT


- 1 Unlock and lift the thermostat cover.



- 2 Connect the heating floor by using the load / line wire connectors located on the back of the thermostat. Connect the ground wire to the screw in the electrical box intended for this purpose.




- 3 Connect the sensor. (Only for control applications in F mode or with floor limit.)




- 4 Use the screws to secure the thermostat to the electrical box.

Replace the cover and lock.




- 5 Power up the thermostat. After performing a test sequence, the thermostat should display the floor temperature. If not, refer to the troubleshooting guide in this manual.



USER SETTINGS

Increasing or lowering the temperature


To adjust the temperature, press \downarrow or \uparrow . The requested temperature will blink to confirm the new setpoint.




USER SETTINGS

Get the setpoint to its minimum and hold the \downarrow button for 5 seconds to access the menu.

Press the \downarrow or \uparrow button to change the setting.



Press the \downarrow and \uparrow buttons simultaneously to save and go to the next parameter. Continue to press until the end of the list to exit the menu.



Settings which can be modified directly on the device:

#	Display	Parameters & settings
1	Temp	Temperature format °C or °F (Default: °C)
2	Backlight	Backlight control ON or OFF – (Default: ON) ON (backlight always active) OFF (will only turn on when a button is pressed)
3	Control	Control mode (Mode not displayed when the ambient temperature is visible on the main screen.) A [Air], F [Floor] (Default: F)
4	Setpoint Min	Minimum setpoint 5 °C to 36 °C (Default: 5 °C)
5	Setpoint Max	Maximum setpoint 5 °C to 36 °C (Default: 36 °C) 36 °C in Floor mode (Default: 36 °C) 30 °C in Air mode (Default: 30 °C)
6	Limit Air Max	Maximum ambient temperature limit (Only visible in F mode) 5 °C to 36 °C (Default: OFF)
7	Limit Floor Max	Maximum floor temperature limit (Only visible in A mode) 5 °C to 36 °C (Default: OFF)
8	Limit Floor Min	Minimum floor temperature limit (Only visible in A mode) 5 °C to 36 °C (Default: OFF)
9	Sensor	Floor sensor 10K or 12K (Default: 10K)

3) The thermostat offers 2 temperature regulation modes:

F mode (default): Regulates the floor temperature by means of an external temperature sensor with the possibility to limit ambient temperature.

A mode: Regulates ambient temperature with the possibility to limit floor temperature by means of an external temperature sensor.

6) Maximum limit of the ambient temperature (F mode)

Thermostat limits floor heating so as not to exceed the set ambient temperature limit

7) Maximum floor temperature limit (A mode)

The thermostat limits floor heating to the set temperature to ensure it does not exceed the selected limit; ideal for protecting engineered wood floors.

8) Minimum floor temperature limit (A mode)

The thermostat limits the minimum temperature of the floor in order to keep it at a comfortable temperature. This parameter can only be used when a floor sensor is connected to the thermostat.

TROUBLESHOOTING GUIDE

What should I do if the EIF code appears on my thermostat's display? The EIF code means that the thermostat is in "Floor" mode and there is no connected sensor. If your thermostat is not intended to control a heated floor, change the thermostat's control mode for the "A mode".

GROUND FAULT PROTECTION

The thermostat is equipped with a ground fault protection that can detect a current leakage of 5 mA. When a current leakage is detected, the ground fault protection is triggered and quickly interrupts the power supply to prevent any serious injuries.

Resetting the ground fault protection

The RESET button warning light turns ON (red) when the ground fault protection is triggered. If the RESET button warning light turns ON during normal operation of the thermostat, simply press the RESET button to reset the ground fault protection. The light will turn OFF. If for any reason this situation occurs again, cut the power to the heating system from the main electrical panel and ask a qualified electrician to verify the installation.

Testing the ground fault protection

This thermostat has an Auto Test which periodically verifies the correct operation of the protection circuit. You can also do this manually:
1) Press the TEST button. If the RESET button's red warning light does not turn ON, the test has failed. Cut the power to the heating system from the main electrical panel and ask a qualified electrician to verify the installation. 2) Press the RESET button to restart the thermostat's base.

TECHNICAL SPECIFICATIONS

Operating voltage: 120/208/240 Vac, 50/60 Hz

Maximum load:

1800 W @ 120 V / 15 A

3120 W @ 208 V / 15 A

3600 W @ 240 V / 15 A

Setpoint range: 41 °F to 97 °F [5 °C to 36 °C]

Ambient setpoint range: 41 °F to 86 °F [5 °C to 30 °C]

Display range: 32 °F to 122 °F [0 °C to 50 °C]

Resolution: ± 1 °F [± 0.5 °C]

Storage: -4 °F to 122 °F [-20 °C to 50 °C]

Auxiliary output: 24 Vac/Vdc / 0.1 A

GFCI protection: Class A (5mA)

WARRANTY

Three (3) year limited warranty. The manufacturer warrants the components of the OTH3600-GA-V2 against defects in material and workmanship for a three (3) year period from the date of purchase, under normal use and service, when proof of purchase of such is provided. The obligation of the manufacturer is limited to replacement of the product (device) only and in no way whatsoever includes the cost of connecting or installing the device or replacement parts.

CUSTOMER SERVICE

If you have any questions about this product, please contact our technical support team:

Ouellet Canada inc.: 1 800 463-7043 • info@ouellet.com
www.ouellet.com

Momento: 1 800 463-7043 • www.momentoconfort.com

Global Commander: 1 855 247-5596 • www.globalcommander.ca
180, 3e Avenue, L'Islet (Québec) G0R 2C0 CANADA

660-0332-0000-A

CONNECT AN EXPANSION UNIT (TR1310)

It is possible to connect up to 10 expansion units to the same device. [EXP function]

