

TECHNICAL DETAILS

KIT-OSA-INS-5

BASIC INSTALLATION KIT FOR AIR EXCHANGERS FROM 100 TO 150 CFM, 5 IN. (127 MM) DUCTS)



INCLUDES

- 2 x Air intake/Exhaust vent Ø 5 in.
- 2 x Round air diffuser with collar Ø 5 in.
- 2 x 25 ft. non-insulated flexible duct Ø 5 in.
- 25 ft. Insulated flexible air duct Ø 5 in.
- 8 x 24 in. tie wrap

KIT-OSA-INS-6

BASIC INSTALLATION KIT FOR AIR EXCHANGERS FROM 150 CFM AND OVER, 6 IN. (152 MM) DUCTS



INCLUDES

- 2 x Air intake/Exhaust vent Ø 6 in.
- 2 x Round air diffuser with collar Ø 6 in.
- 2 x 25 ft. Non-insulated flexible duct Ø 6 in.
- 25 ft. Insulated flexible air duct Ø 6 in.
- 8 x 24 in. tie wrap

KIT-SA-FI-115

KIT OF 2 FILTERS FOR 115R ERV AIR EXCHANGER



INCLUDES

- 2 filters for 115R ERV air exchanger

KIT-SA-FI-230

KIT OF 2 FILTERS FOR 230R ERV AIR EXCHANGER



INCLUDES

- 2 filters for 230R ERV air exchanger